



Tip: Sand and testfit every part before glue

Step 1: Start with the 6 arm parts and glue them together and it should look like this above.